Philips
Bun warmer

CRP179

Bun warming rack to warm buns and croissants

Bun warming rack to warm buns and croissants

Ease of using Philips spare parts

- Renew your product with original Philips parts

PHILIPS
sense and simplicity

Specifications

Replaceable part

HD2589/20

- Fits product types:: HD2586/20, HD2587/20,

Highlights

Easy replacement

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality and 1:1 exchange.

Issue date 2011-10-13

Version: 1.0.1

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com